





































Spare Parts 配件表

			
1030A Body 车壳组件	10100 Front Bumper Assembly 前防撞组件	10110 Rear Bumper 后防撞	10120 Wheelie Bar Assembly 抬头轮
			
10130 Chassis Parts 底盘配件	10131 Motor Shell 电机安装座	10150 Servo Mount 舵机支架	10300 Chassis 底盘
			
10310 Center Brace Bar 中支撑杆	1031F Front Stiffener 前加强件	1031R Rear Stiffener 后加强件	10160 Front Upper Gearbox Covers 前齿轮盖













Spare Parts 配件表

			
10190 Rear Upper Gearbox Covers 后齿轮盖	10191 Vise Jaw 波箱盖	10270 Front Shock Tower 前避震架	10280 Rear Shock Tower 后避震架
			
10200 Rod 拉杆	10220 Front Lower Suspension Arms 前下摆臂	10230A Steering Block 转向座	10230B Steering Block 转向座
			
10240 Rod 拉杆	10250 Rear Lower Suspension Arms 后下摆臂	10260 Rear Hubs 后固定座	10501 Shock Safeguard 避震保护












Spare Parts 配件表

10121	Front/Rear Sway Bar 前/后防倾杆	
10320	Receiver Box 接收盒	
Z3060	F/R Lower Swing Arm Fixed Shaft 下摆臂固定轴	
M10400	F/R Reinforced Sheet 前后加强件	
S3580R	Servo 舵机	
10702	Servo Swingarm 舵机摆臂	
10430	Steering Assembly 转向传动组件	
10432	Connecting Rod 转向连杆	
B3970A	Brushless Motor 无刷电机	
10392	Motor Pinions 电机输出齿	
10393	Motor Guard 电机固定座	
10395	Motor Heatsink 散热片	

Spare Parts 配件表

10397	ESC Fan 电调风	
10420C	Center Differential 中央差速器	
10420	Front/Rear Differential 前/后差速器	
10192	Gearbox Housings 差速器外壳	
10402	Front Drive Teeth 前伞齿	
10402R	Rear Drive Teeth 后伞齿	
10403	Centre Drive Shaft 主轴	
E100A	Brushless ESC 无刷电子调速器	
R30	Receiver 接收器	
T3B	Transmitter 遥控器	
10510	Oil Filled Shock (Front) 油压避震(前)	
10500	Oil Filled Shock (Rear) 油压避震(后)	

Spare Parts 配件表

	 	 	
10410	10440	1015A	M40
Metal F/R CVD Shafts (2 Sets) 轮胎转动组件	Wheel Hex 六角套	Wheel Assembly 车轮组件 (2PCS)	M4 Wheel Lock Nut M4螺母 (8PCS)
			
BD2217	P812	T70367	T65348
Battery Base 电池固定带 (2PCS)	Hexagonal Wrench 六角扳手	Bushing 轴套 (8PCS)	Bushing 轴套 (8PCS)
			
PH02			
Screwdriver Sets 螺丝刀套装			

Screws 螺丝

M3030	Ø3x3mm	12PCS
M3080	Ø3x8mm	12PCS
HTM3010	Ø3x10mm	12PCS
HTM3012	Ø3x12mm	12PCS
HTM3014	Ø3x14mm	12PCS
HTM3016	Ø3x16mm	12PCS
HTM3060	Ø3x6mm	12PCS
HKM3012	Ø3x12mm	12PCS
HTHM30135	Ø3x13.5mm	12PCS
HKM3080	Ø3x8mm	12PCS
HTM3020	Ø3x20mm	12PCS
HTHM3049	Ø3x49mm	12PCS
HTHM3040	Ø3x40mm	12PCS
HWM4030	Ø4x3mm	12PCS
HHM4080	Ø4x8mm	12PCS

Others 其他

BRG10154	Bearing 轴承	8PCS
R168Z	Bearing 轴承	8PCS
M30	Ø3mm Nut 螺母	8PCS
M40	Ø4mm Nut 螺母	8PCS